

## SGR1500 MR Mastic Remover Application Instructions

### SGR1500 Mastic Remover

[YouTube - SEALGREENTV](#)

Due to variances in concrete surfaces and conditions, test in an inconspicuous area before using on complete project. **DO NOT** use on wood as it may stain.

#### Directions:

1. Pour **SGR1500 Mastic Remover** undiluted directly onto the substrate.
2. Use a long handled brush, thick nap roller or broom to ensure the **SGR1500** generously covers all trowel ridges. Allow **SGR1500 Mastic Remover** to sit until mastic softens. Asbestos mastic generally softens in 45-60 minutes. Vinyl and latex mastics can take up to 4 hours to soften. The longer the product remains without drying, the better the results. We recommend 8 to 12 hours
3. After mastic has softened, remove with a long handle scraper or squeegee.
4. Clean **SGR1500** residue from the surface with the **SealGreen™ Oil Cleaner/ Degreaser™** concentrate which is included with your order.
5. Let the surface dry before applying new mastic or coating. In all cases, care should be taken not to over-saturate the floor by using too much water.

For porous and/or cracked substrates, after scraping up mastic, use a commercial absorbent (inexpensive cat litter) to help with clean-up before using SealGreen Oil Cleaner/ Degreaser Concentrate to clean the surface.

To test the surface for residue after the floor has been cleaned: apply water to various small spots on the floor. If the water turns cloudy white, it indicates there is **SGR1500 Mastic Remover** on the surface, then reapply **SealGreen™ Oil Cleaner/ Degreaser™** Concentrate. Test and clean until the water is clear.

**Square foot coverage varies depending, in part, on type and age of coating, number of layers and method of coating application.**  
**Based on customer reports average coverage**

is:

30 Sqft. per a quart  
120 Sqft. per gallon  
600 Sqft. per five gallon pail

#### Temperature:

**SGR1500** performs better when the **floor temperature** is between 65 and 90 Degrees Fahrenheit. Temperatures below 65 degrees will slow down the effectiveness of the product.

#### Helpful tips for using SGR1500

- \* Use **SGR1500** generously to thoroughly cover trowel ridges.
- \* Give **SGR1500** time to work. 45 – 60 minutes is typical for asbestos mastic. Vinyl and acrylic mastics may take up to 4 hours. **We recommend 8-12 hours for all glues and mastics.**
- \* After scraping up mastic, use **SealGreen Oil Cleaner/ Degreaser** to clean up. The cleaner is included with **SGR1500** order.
- \* **SGR1500** is not recommended for use on wood surfaces or drywall.
- \* **SGR1500 may slightly darken concrete surfaces.**

**Warranties:** The manufacturer warrants only that the product delivered will be merchantable and workmanship at the time sold. Under no circumstances are we liable for loss damage, expenses, or consequential damages arising from use of or inability to use our product.

#### SealGreen—ReUse Concrete Sealing

16072 Foster St.  
Overland Park, KS 66085  
[www.SealGreen.com](http://www.SealGreen.com)  
800-997-3873  
[YouTube - SEALGREENTV](#)