

# Tintable Sealer and Color Mix Instructions

Update 5-16-2026

We will stain and seal 2,250 square feet of new, plain concrete driveway. The concrete is new, and the entire surface will be stained and sealed.

1. After cleaning the entire driveway with [SealGreen Color Stain Primer Cleaner](#) (you will need 2 bags of cleaner), let the driveway dry naturally. Because of the size of the driveway, allow it to dry overnight.
2. **Tools** - You will need (3) 5-gallon pails with reusable lids, a mixing stick, (2) 1-quart measuring cups, and clean water. You will also need a garden pump sprayer, rollers, and a small 4-inch brush for trimming.
3. Label each pail as **S = Sealer**, **C = Color**, and **M = Mixed sealer/color ready to apply**.
4. For this job, you will need **1 gallon and 2 quarts of [SealGreen Tintable Concentrate Sealer](#)** and **12 quarts of [SealGreen color stain concentrate](#)**.
  - a. **The standard color mix** for concrete that looks like regular concrete is 1 quart of White color #100 mixed with 1 quart of Natural color #110.



- b. **Custom color** - For this job, a lighter gray tone is desired, so mix 2 quarts of White color #100 with 1 quart of Natural color #110. This means you will need 8 quarts of White color #100 mixed with 4 quarts of Natural color #110.
5. Start by mixing the **SealGreen Tintable Concentrate Sealer**. Pour the 2 quarts of concentrated sealer into **pail S**, then fill **pail S** with water to within 1 inch of the top. You now have 5 gallons of sealer ready to use.
  6. Pour 8 quarts of White color #100 and 4 quarts of Natural color #110 into **pail C**, then mix until the color is uniform. You now have 12 quarts of mixed color in **pail C**.
  7. Pour 4 quarts of color from **pail C** into **pail M**, then add 16 quarts of sealer from **pail S** into **pail M**. Mix until the color is uniform. You now have 20 quarts of ready-to-apply color/sealer for the driveway.
  8. Use a garden pump sprayer with a fan tip to apply the product. Spray evenly across the surface and do not overapply. Immediately after spraying, back-roll the wet area

with a 1/2-inch nap roller. You may use either a 9-inch or 18-inch roller. Continue this process until the entire surface is covered. Work in sections to avoid dry lines. Also avoid applying the product to a hot surface, as this can cause flash drying.

9. Let the driveway dry naturally. After it dries, if you see areas that need more color, apply a light additional coat and back-roll again.
10. Allow the driveway to dry for at least 12 hours before opening it to regular traffic.
11. The result will be a stained and sealed driveway with a matte finish.
12. Depending on weather exposure and traffic, maintenance will typically be needed every 4 to 5 years. To maintain the finish, repeat the procedure above.