
SealGreen W10 Finish Coat

The SealGreen W10 Finish Coat is a roller or microfiber mop applied emulsion to provide a high gloss sacrificial coat to the surface. It can be used as often as needed or desired as a maintenance gloss coat.

The SealGreen E10 High Performance Sealer is typically applied directly over the stained concrete surface and the W10 Finish Coat after the SealGreen E10 High Performance Sealer has cured for 24 hours.

Dry Time: 1.5 hours. Coverage: 1,400 to 1,900 square feet per gallon. Finish: High Gloss

The more coats the glossier the floor.

First Time Application: Apply with a short nap roller. When dry buff with a microfiber towel or pad. W10 Finish Coat can be applied with a pump sprayer with a fan tip followed by a back roll with the appropriate roller cover.

Use short nap shed-free roller (3/8" or max 1/4"). You want an even coat that gets substrate totally covered but without pooling. If the surface has a profile you may use a 1/2 inch to 1-1/4 inch shed-free nap roller without pooling.

Roll in standard "V"/"W" pattern. Lay down with back roll as below:

Pour small amount on floor to load roller and create a "V" or "W" in a 4' x 4' area.

Working in a pull/push mode (away from you and towards you) quickly spread the material. Use one hand only to hold the roller, do not apply pressure to the roller handle when rolling, pressure will thin the coat. The idea is just to spread material evenly while avoiding leaving lines on the surface when applying the product. Roll at a lower speed to avoid creating bubbles.

LIGHTLY BACKROLL. *Do not overwork.* Repeat the above adjacent to the first area, overlapping the new "V"/"W" slightly into the old. Work fast so that overlaps are wet to wet.

For added durability on high traffic areas, acid staining, very porous substrates, or potential standing water, apply three coats with second and third coat applied when previous coats are *print-free* and *totally clear* (no haze). This will vary depending on room temperature. *NOTE: If you have applied a very heavy coat, especially under cool conditions/low air circulation, time until clear will increase.*

When final coat of SealGreen W10 is print free or totally clear (no haze), typically in 1.5 hours floor will be available for foot traffic.

Maintenance Application: Pour small amount on floor to load a microfiber pad. Apply as needed. typical drying time is 1 hour.

Buffing: After W10 has dried, a light buff with a white pad is optional for regular maintenance.