

1. Select area in the middle of the floor and clean to remove any paint or coatings. If washed wait 24 hours to dry before test is placed.



2. Hold container firmly (as in the picture) and remove blue tape carefully. Do not spill or open capsule.



3. Stick the tape to the edge of the clear plastic cover. Insure that the tape from test 1 is attached to the clear test cover 1. The tape will be used again at the end of the test.



4. Fill in the blanks on the left side of the container (time and date). Place container on floor in the middle of the clean area and open carefully.



5. Remove paper from seal below the clear cover and place it over the open capsule. Press evenly around the cover edges to eliminate any open areas .



6. Leave test in place for 72 hours. After test is completed, remove the cover carefully with a stiff spatula. Close the capsule carefully and re-tape the capsule with the original blue tape (see step 2). Fill in the blanks on the right side of the capsule. Also record the PH level. Mail the capsule only to ReUse Concrete Sealing.