

SealGreen E10 High Performance Sealer Test

Test Instructions for Old, New, Stamped Concrete, Colored Concrete, Acid-Stained Concrete/Cements (Interior or Exterior) and Gypsum Flooring

To provide a true test please follow the following Instructions:

- 1. Select two areas that are 6 inches by 6 inches on the floor where a test can be applied.
- First Test Area should be where the concrete shows white or milky stains due to old sealer failure. Second Test Area should be where the sealer still looks good. Please select areas that are NOT going to be in a very visual place.
- 3. Spray the areas to be tested with the **SealGreen Oil Cleaner Degreaser** and allow to remain in place for 5 minutes before rinsing with clean water or wiping with a damp clean cloth or paper towel.
- 4. Allow the test areas to dry for 20 minutes. The dry test area should look like it did before cleaning.
- 5. Pour a small amount of the SealGreen E10 Epoxy Sealer over the two areas and spread with a brush to cover the entire test area. Do NOT allow to puddle. The E10 initially is milky color but as it dries it will become clear and have some gloss. The more coats you apply, the glossier it gets. Or for a very high gloss, finish with W10 Finish Coat. http://sealgreen.com/W10-finish-coat-concrete-sealer.aspx SealGreen W10 Finish Coat is NOT recommended for outside.
- 6. Allow to dry for 20 minutes.

7. Test results evaluation:

- c. First Test Area where the milky spots from the old sealer breaking down The SealGreen E10 test clear the white stains and leave the floor with its original color and some gloss. If this is true then SealGreen E10 is the perfect solution to restoring the color and sealing your concrete.
 - To obtain more information on **SealGreen E10 Epoxy Sealer** visit: http://sealgreen.com/E10-epoxy-concrete-sealer.aspx and **SealGreen Oil Cleaner Degreaser** http://sealgreen.com/Oil-Cleaner-Degreaser.aspx
- d. Second Test Area where the sealer was colorful and clear The floor should look rich in color and glossy after the SealGreen E10 Epoxy Sealer has dried. If the application of the SealGreen E10 Epoxy Sealer has crinkled the old sealer and makes the surface rough this is a sign that the SealGreen E10 Epoxy Sealer is not compatible with the old sealer and has created a chemical reaction. If this is the case, in order to restore the color and seal the floor you will need to strip the old sealer from the concrete before any other sealer is applied. To remove the old sealer from the floor we recommend using SealGreen 600GL Soy Gel Paint and Sealer Remover available at http://sealgreen.com/soy-gel-paint-and-urethane-remover-for-concrete-and-wood.aspx